

wiring diagram head unit

wiring diagram head unit is an essential resource for anyone looking to install, troubleshoot, or upgrade their car audio system. Understanding the wiring diagram of a head unit allows technicians and enthusiasts to connect speakers, power sources, antennas, and other components accurately. This article explores the critical aspects of wiring diagrams for head units, covering common wire color codes, connection methods, and compatibility considerations. It also discusses how to read these diagrams effectively and the tools required for a successful installation. Whether upgrading to a modern touchscreen system or replacing a factory head unit, mastering the wiring diagram is crucial for ensuring optimal audio performance and system reliability. The following sections provide a detailed guide on wiring diagram head units, including practical tips and safety measures.

- Understanding Wiring Diagrams for Head Units
- Common Wire Color Codes and Their Functions
- Step-by-Step Guide to Reading a Wiring Diagram Head Unit
- Tools and Materials Needed for Head Unit Wiring
- Installation Tips and Best Practices
- Troubleshooting Wiring Issues

Understanding Wiring Diagrams for Head Units

A wiring diagram head unit is a schematic representation that shows the electrical connections and functions of the various wires involved in the car audio system. It serves as a roadmap for connecting the head unit properly to the vehicle's power supply, speakers, antenna, and auxiliary components. These diagrams are essential for ensuring that each wire is connected correctly to avoid damage to the head unit or the vehicle's electrical system. They illustrate the flow of electricity and signal paths, which helps in diagnosing faults or upgrading components.

Purpose of a Wiring Diagram Head Unit

The primary purpose of a wiring diagram head unit is to provide clarity on the wiring layout of the head unit and its integration with the vehicle's electrical system. It helps installers:

- Identify power and ground wires
- Locate speaker wires and their polarity
- Understand additional wire functions such as illumination, antenna control, and remote turn-on
- Prevent incorrect wiring that could cause short circuits or damage

By following a wiring diagram, installers can ensure compatibility and proper functionality of the head unit within the vehicle.

Common Wire Color Codes and Their Functions

Wiring diagram head units typically follow standardized color codes to denote specific functions of each wire. Familiarity with these colors is critical for correct installation and troubleshooting. Although some manufacturers may vary slightly, most follow a general color scheme recognized industry-wide.

Standard Wire Colors in Head Unit Wiring

The following is a list of common wire colors and their typical functions in a wiring diagram head unit:

- **Yellow:** Constant 12V power (battery)
- **Red:** Accessory 12V power (ignition)
- **Black:** Ground wire
- **Blue:** Power antenna or amplifier turn-on
- **White/White with Black Stripe:** Front left speaker (positive and negative)
- **Gray/Gray with Black Stripe:** Front right speaker (positive and negative)
- **Green/Green with Black Stripe:** Rear left speaker (positive and negative)
- **Purple/Purple with Black Stripe:** Rear right speaker (positive and negative)
- **Orange:** Illumination or dimmer control

Understanding these color codes aids in accurately connecting the head unit wires to the corresponding vehicle wiring harness.

Step-by-Step Guide to Reading a Wiring Diagram Head Unit

Reading a wiring diagram head unit requires attention to detail and understanding of electrical schematics. The following steps outline a methodical approach to interpreting these diagrams successfully.

Identify the Key Components

Begin by locating the main components on the wiring diagram such as the head unit, speakers, power sources, and any accessories like amplifiers or antennas. This helps in understanding the overall layout and purpose of each wire.

Trace the Wiring Paths

Follow each wire's path from the head unit to its destination. Note the wire color, labels, and any connectors or splices along the route. This tracing ensures that each connection is correctly identified and mapped out.

Understand Wire Functions

Refer to the color codes and the diagram's legend to determine each wire's function. For example, identifying which wires provide power, ground, or speaker output is critical to avoid wiring errors.

Check for Additional Features

Modern head units may include wires for remote turn-on, illumination, steering wheel controls, and more. Ensure these are correctly identified and connected according to the diagram to maintain full functionality.

Verify Connector Types

Many wiring diagrams show connector types and pin configurations. Matching these with the vehicle's harness connectors ensures a secure and compatible installation.

Tools and Materials Needed for Head Unit Wiring

Proper tools and materials are necessary to execute wiring diagram head unit instructions effectively. Having the right equipment ensures clean, reliable

connections and reduces installation time.

Essential Tools for Wiring

- Wire strippers and cutters
- Crimping tool for connectors
- Multimeter for voltage and continuity testing
- Soldering iron and solder (optional for permanent connections)
- Electrical tape or heat shrink tubing
- Wire connectors such as butt connectors or quick disconnects
- Panel removal tools to access the vehicle's dashboard

Using these tools in conjunction with a wiring diagram head unit ensures a professional and safe installation process.

Installation Tips and Best Practices

Following best practices during installation based on the wiring diagram head unit improves system performance and durability. Attention to detail and adherence to safety guidelines are paramount.

Best Practices for Wiring Head Units

- **Disconnect the vehicle battery** before starting to prevent electrical shorts.
- **Use the correct wire gauge** for power and speaker wires to handle current safely.
- **Double-check wire color codes** against the wiring diagram before making connections.
- **Secure all wires** away from moving parts and sharp edges to avoid damage.
- **Test all connections** with a multimeter before finalizing the installation.
- **Use heat shrink tubing** or electrical tape to insulate exposed wires.

- **Refer to the vehicle's service manual** for any model-specific wiring information.

Implementing these tips ensures a safe, functional, and professional-quality installation.

Troubleshooting Wiring Issues

Even with a wiring diagram head unit, issues may arise during installation or use. Systematic troubleshooting can identify and resolve these problems effectively.

Common Wiring Problems and Solutions

Common issues include no power to the head unit, distorted sound, or non-functioning accessories. Troubleshooting steps include:

1. **Check power and ground connections:** Verify with a multimeter that the head unit receives 12V constant and switched power and has a proper ground.
2. **Inspect speaker wiring:** Ensure correct polarity and secure connections to prevent sound distortion or imbalance.
3. **Test fuses:** Replace any blown fuses in the vehicle's fuse box or head unit circuit.
4. **Verify remote turn-on wire:** Confirm the amplifier or power antenna wire activates properly.
5. **Look for shorts or open circuits:** Check for damaged wires or loose connections that could interrupt signals.

Following the wiring diagram head unit carefully during troubleshooting improves the chances of quickly restoring full functionality.

Frequently Asked Questions

What is a wiring diagram for a head unit?

A wiring diagram for a head unit is a visual representation that shows how to connect the electrical wires from the vehicle to the head unit, including power, ground, speakers, and auxiliary connections.

How do I read a head unit wiring diagram?

To read a head unit wiring diagram, identify the color codes for each wire, understand the symbols representing components, and follow the paths connecting power, ground, speakers, antenna, and additional features.

Can I use a universal wiring diagram for any car head unit installation?

While universal wiring diagrams provide a general guide, it's important to consult the specific wiring diagram for your car model and head unit to ensure compatibility and avoid damaging the electrical system.

What do the different colored wires in a head unit wiring diagram represent?

In most head unit wiring diagrams, wire colors have standard meanings: red for accessory power, yellow for constant power, black for ground, blue for antenna or amplifier remote turn-on, and various colors for speaker connections.

How can I safely connect a new head unit using a wiring diagram?

To safely connect a new head unit, first disconnect the vehicle's battery, use the wiring diagram to match wire colors correctly, secure all connections with proper connectors or soldering, and test the system before fully reassembling.

Additional Resources

1. *Understanding Head Unit Wiring Diagrams: A Comprehensive Guide*

This book offers an in-depth exploration of wiring diagrams specifically for automotive head units. It covers basic electrical concepts, common wiring colors, and how to interpret complex diagrams. Whether you are a beginner or an experienced installer, this guide helps simplify the process of wiring head units.

2. *Automotive Head Unit Installation and Wiring Manual*

Designed for both professionals and hobbyists, this manual provides step-by-step instructions on installing and wiring car stereo head units. It includes detailed diagrams, troubleshooting tips, and safety precautions. The book emphasizes practical knowledge to ensure successful installations.

3. *Mastering Car Audio Wiring: Head Unit and Beyond*

This title focuses on the wiring aspects of car audio systems, with a special section dedicated to head unit connections. Readers will learn about power

distribution, grounding techniques, and signal wiring. The book also covers upgrading factory systems and integrating aftermarket components.

4. Head Unit Wiring Diagrams Explained: A Visual Approach

Using clear visuals and annotated diagrams, this book demystifies the wiring of automotive head units. It breaks down complex wiring layouts into understandable segments, making it easier to follow and apply. Ideal for visual learners and DIY enthusiasts.

5. DIY Car Stereo Wiring: Head Unit Edition

This practical guide focuses on do-it-yourself car stereo wiring projects, with detailed sections on head unit wiring diagrams. It includes tips on selecting the right tools, avoiding common mistakes, and customizing wiring for various vehicle models. Perfect for those looking to upgrade their car audio systems independently.

6. Electrical Wiring for Car Audio Head Units

This technical book delves into the electrical principles behind head unit wiring, including voltage requirements, current flow, and circuit protection. It offers wiring diagrams alongside explanations of each component's role within the system. A valuable resource for understanding the electrical side of car audio installation.

7. Head Unit Wiring and Integration with Vehicle Systems

Focusing on the integration of head units with modern vehicle electronics, this book covers wiring diagrams in the context of CAN bus systems, steering wheel controls, and factory amplifiers. It provides guidance on maintaining system compatibility and avoiding electrical conflicts. Essential for installers working with newer vehicles.

8. Car Head Unit Wiring Troubleshooting Guide

This guide is dedicated to diagnosing and fixing wiring issues related to automotive head units. It includes common wiring faults, how to read wiring diagrams to identify problems, and practical repair techniques. A handy reference for anyone facing head unit connectivity or power issues.

9. Advanced Wiring Techniques for Car Audio Head Units

Targeted at experienced installers, this book explores advanced wiring methods such as soldering, harness modifications, and custom wiring harness creation. It features complex wiring diagrams and tips for optimizing audio performance through proper wiring. A must-have for professionals seeking to enhance their wiring skills.

Wiring Diagram Head Unit

Find other PDF articles:

<http://www.devensbusiness.com/archive-library-709/Book?dataid=ZG176-6728&title=teacher-student-sexual-relationship.pdf>

wiring diagram head unit: *The Ultimate Guide On Installing Your After Market Car Stereo*

Ryan Keeler, 2024-02-22 The Ultimate Guide on Installing Your After Market Car Stereo by Ryan Keeler is a comprehensive guide published on February 22, 2024, aimed at audiophiles and vehicle enthusiasts who wish to upgrade their car audio systems. This detailed manual covers everything from the basics of car audio systems to the intricate steps involved in installing various components like head units, speakers, amplifiers, and subwoofers. Ryan Keeler meticulously explains the tools and techniques required for each stage of the installation process, ensuring that even those new to car audio can understand and follow the procedures. The guide emphasizes the importance of proper planning, selecting the right components, and the technical know-how necessary to achieve the best sound quality and system functionality. It includes detailed sections on the electrical fundamentals relevant to car stereo systems, such as wiring diagrams, grounding, and connectivity issues, along with troubleshooting tips for common installation challenges. Additionally, the book delves into advanced topics like integrating modern technology with traditional car audio systems, including Bluetooth connectivity, smart device integration, and navigation systems. Keeler also addresses aesthetic considerations, ensuring that the installation not only sounds good but also looks professional within the vehicle's existing interior. Overall, this guide is an invaluable resource for anyone looking to upgrade their car stereo system, providing practical advice and professional insights to ensure a successful installation that enhances the in-car audio experience.

wiring diagram head unit: *Car Audio For Dummies* Doug Newcomb, 2008-02-11 Thinking about a knockout audio system for your car? Not sure what you need, want, or can afford? Car Audio For Dummies is a great place to find some answers! But wait — what if speakers that vibrate your floorboards don't turn you on? What if you're thinking more about hands-free phone access and a DVD player to entertain the kids? Surprise! Car Audio For Dummies can give you a hand there, too. Whether you want to feel as if your favorite band is performing right on top of your dashboard or you want to keep the soccer team entertained on the way to the tournament, this friendly guide can help. From planning your system and buying components to getting them installed and protecting your investment, you'll find plenty of wise advice. Get the scoop on: Figuring out what kind of equipment you need to do what you want Identifying good sound quality when you hear it Adding components to a factory system Choosing a video player, hands-free phone system, amplifiers, speakers, and more Finding a reliable installer (today's automotive electronics systems are so complex that you probably won't want to go it alone) Understanding warranties and returns Protecting and insuring your system Car Audio For Dummies is sort of like that knowledgeable friend you want to take along when you tackle a project like this. Sounds like a good idea, doesn't it?

wiring diagram head unit: *Car Stereo Cookbook* Mark Rumreich, 2005-05-21 The first edition of this book was written six years ago. Since then, there have been some significant developments in the area of car audio (and video). In addition, many of the products featured in the first edition are now obsolete. While the first edition of the book continues to sell, we have seen a bit of a slow-down at major accounts. This edition promises to be even more successful than the last. Car Stereo Cookbook, 2e is a completely revamped edition of a hugely successful title that continues to sell. This revised book will include new information on mobile video, satellite radio, mp3, wma, digital broadcast radio, and will eliminate the out-of-date products that are no longer pertinent.

wiring diagram head unit: *Technical Manual* United States. War Department, 1944

wiring diagram head unit: *CRE* , 1957

wiring diagram head unit: *How to Design and Install In-Car Entertainment Systems* Jefferson Bryant, 2009 The Ultimate Guide to In Car Entertainment presents the entire spectrum of audio/video, navigation, communication, and entertainment technology, and how the enthusiast can create a complete custom system or an integrated stock/aftermarket system. It explains how to plan, select, integrate and install popular systems under a specific budget for a certain level of performance. This includes design and installation considerations for audio and video, such as DVD players, TV tunes, and video screens (in-dash, in-seat, overhead, rear truck, etc.) GPS navigation,

video game systems (PS3, X-Box 360, and more), iPod integration with head units, satellite radio, digital audio broadcasting, car security and even computers (carputers). The book features how-to installations, thorough explanations of professional only builds, descriptions of hook-ups, mechanical upgrades, such as charging systems, and a comprehensive resource guide.

wiring diagram head unit: ,

wiring diagram head unit: Engineering Materials List U.S. Atomic Energy Commission, 1958

wiring diagram head unit: **Aviation Ordnancemen's Manual, AO.** United States. Office of the Chief of Naval Operations, United States. Department of the Navy. Bureau of Aeronautics, 1958

wiring diagram head unit: **MOS 63H Track Vehicle Repairer, Skill Level I** , 1985

wiring diagram head unit: *Drawings for the Watts Bar Project* , 1948

wiring diagram head unit: **Engineering Materials List** , 1963

wiring diagram head unit: **Manuals Combined: 150+ U.S. Army Navy Air Force Marine Corps Generator Engine MEP APU Operator, Repair And Parts Manuals** , Over 36,000 total

pages Just a SAMPLE of the CONTENTS by File Number and TM Number:: 013511 TM 5-6115-323-24P 4 GENERATOR SET, GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULAR FRAME, 1.5 K SINGLE PHASE, AC, 120/240 V, 28 VDC (LESS ENGINE) DOD MODELS MEP-015A, 60 HZ (NSN 6115-00-889-1446) AND (DOD MODEL MEP-025A) 28 VDC (6115-00-017-8236) {TO 35C2-3-385-4; SL 4-07609A/07610A} 013519 TM 5-6115-329-25P 1 GENERATOR SET, GASOLINE ENGINE DR (LESS ENGINE) 0.5 KW, AC, 120/240 V, 60 HZ, 1 PHASE (DOD MODEL (FSN 6115-923-4469); 400 HZ (MODEL MEP-019A) (6115-940-7862) AN DC (MODEL MEP-024A) (6115-940-7867) {TO 35C2-3-440-14} 013537 TM 5-6115-457-12 7 GENERATOR SET, ENGINE DRIVEN, TACTICAL, SKID MTD; 100 KW, 3 PHASE, 4 WIRE, 120 240/416 V (DOD MODELS MEP-007A), UTILITY CLASS, 50/60 HZ (NSN 6115-00-133-9101), (MODEL MEP-106A) PRECISE CLASS, 50/60 H (6115-00-133-9102), (MODEL MEP-116A) PRECISE CLASS, 400 KW (6115-00-133-9103) INCLUDING OPTIONAL KITS (MODEL MEP-007 AWF) WINTERIZATION KIT, FUEL BURNING (6115-00-463-9082), (MEP-007AWE WINTERIZATION KIT, ELECTRIC (6115-00-463-9084), (MODEL MEP-007A DUMMY LOAD KIT (6115-00-463-9086) AND (MODEL MEP-007AWM) WHEEL 013538 TM 5-6115-457-34 12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID 100 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 V (DOD MODELS MEP0 UTILITY CLASS, 50/60 HZ (NSN 6115-00-133-9101); (MODEL MEP106A) CLASS, 50/60 HZ (6115-00-133-9102) AND (MODEL MEP116A), PRECISE 400 HZ (6115-00-133-9103); INCLUDING OPTIONAL KITS (DOD MODELS MEP007AWF) WINTERIZATION KIT, FUEL BURNING (6115-00-463-9082); MEP007AWE) WINTERIZATION KIT, ELECTRIC (6115-00-463-9084); (MOD MEP007ALM) DUMMY LOAD KIT (6115-00-463-9086) AND (MODEL MEP007A MOUNTING KIT (6 013540 TM 5-6115-458-24P 9 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MTD., 2 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS, DOD MODELS MEP009A UTILITY CLASS, 50/60 HZ (NSN 6115-00-133-9104) AND MODEL MEP108A PRECISE CLASS, 50/60 HZ (6115-00-935-8729) INCLUDING OPTIONAL K DOD MODELS MEP009AWF, WINTERIZATION KIT, FUEL BURNING (6115-00-403-3761), MODEL MEP009AWE, WINTERIZATION KIT, ELECTRIC (6115-00-489-7285) 013545 TM 5-6115-465-12 19 GENERATOR DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 30 KW, 3 PHASE, 4 WIRE 120/208 AND 240/416 V (DOD MODEL MEP-005A), UTILITY CLASS, 50/6 (NSN 6115-00-118-1240), (MODEL MEP-104A), PRECISE CLASS, 50/60 (6115-00-118-1247), (MODEL MEP-114A), PRECISE CLASS, 400 HZ (6115-00-118-1248) INCLUDING AUXILIARY EQUIPMENT (DOD MODEL MEP WINTERIZATION KIT, FUEL BURNING (6115-00-463-9083), (MODEL MEP- WINTERIZATION KIT, ELECTRIC (6115-00-463-9085), (MODEL MEP-005A LOAD BANK KIT (6115-00-463-9088) AND (MODEL MEP-005AWM), WH 013547 TM 5-6115-465-34 12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTIC SKID MTD, 30 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 V (DOD MO MEP-005A), UTILITY, 50/60 HZ (NSN 6115-00-118-1240), (MODEL MEP-104A), PRECISE, 50/60 HZ (6115-00-118-1247), (MODEL MEP-114 PRECISE, 50/60 HZ (6115-00-118-1248) INCLUDING OPTIONAL KITS (MODEL MEP-005AWF) WINTERIZATION KIT, FUEL BURNING (6115-00-463 (MODEL MEP-005AWE)

WINTERIZATION KIT, ELECTRIC (6115-00-463-908 (MODEL MEP-005ALM) LOAD BANK KIT (6115-00-463-9088) (MODEL MEP- WHEEL MOUNTING KIT (6115-00 013548 TM 5-6115-545-12 18 GENERATOR DIESEL ENGINE DRIVEN, TACTICAL SKID MTD., 60 KW, 3 PHASE, 4 WIR 120/208 AND 240/416 VOLTS, DOD MODEL MEP-006A, UTILITY CLASS, 5 (NSN 6115-00-118-1243) DOD MODEL MEP-105A, PRECISE CLASS, 50/60 (6115-00-118-1252) DOD MODEL MEP-115A, PRECISE CLASS, 400 HZ (6115-00-118-1253) INCLUDING OPTIONAL KITS, DOD MODEL MEP006AWF WINTERIZATION KIT, FUEL BURNING (6115-00-407-8314) DOD MODEL MEP006AWE, WINTERIZATION KIT, ELECTRIC (6115-00-455-7693) DOD M MEP006ALM, LOAD BANK KIT (6115-00-407-8322) DOD MODEL MEP006 013550 TM 5-6115-545-34 12 INTERMEDIATE (FIELD) (DIRECT AND GENERAL SUPPORT) AND DEPOT MAINTENANCE MANUAL FOR GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MTD., 60 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS DOD MODELS MEP-006A, UTILITY CLASS, 50/60 HZ (FSN 6115-118-1243 MEP-105A, PRECISE CLASS, 50/60 HZ (6115-118-1252) AND MEP-115A, PRECISE CLASS, 400 HZ (6115-118-1253) {TO 35C2-3-444-2; NAVFAC P-8-626-34; TM 00038G-35} 015378 TM 5-6115-323-14 10 GENERATOR GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULAR FRAME, 1.5 KW, SI PHASE, AC, 120/240 V, 28 V, DC (LESS ENGINE) (DOD MODELS MEP-01 60 HZ (NSN 6115-00-889-1446) AND (MODEL MEP-025A) 28 V DC (6115-00-017-8236) {TO 35C2-3-385-1} 015380 TM 5-6115-332-24P 3 GENERATOR GASOLINE ENGINE: AIR COOLED, 5 KW, AC, 120/240 V, SINGLE PHASE; 120/208 V, 3 PHASE, SKID MOUNTED, TUBULAR FRAME (LESS ENGINE) M DESIGN: 60 HZ (DOD MODEL MEP-017A) (NSN 6115-00-017-8240); 400 (DOD MODEL MEP-022A) (6115-00-017-8241) {TO 35C2-3-424-24} 020611 LO 5-6115-457-12 GENERATOR SET, DIESEL ENGINE DRIVEN; SKID MTD, 100 KW, 3 PHASE, 120/208 AND 240/416 V (DOD MODELS MEP-007A), UTILITY CLASS, 50/ (NSN 6115-00-133-9101); (MODEL MEP-106A) PRECISE CLASS, 50/60 H (6115-00-133-9102) AND (MODEL MEP-116A), PRECISE CLASS, 400 HZ (6115-00-133-9103) 020612 LO 5-6115-458-12 GENERATOR SET, DIESEL ENGINE DRIVEN, SKID MTD, 200 KW, 3 PHASE, 4 WIRE, 120/208/416 VOLTS, DOD MODELS MEP-009A, UTILITY CLASS, 50/60 HERTZ (NSN 6115-00-133-9104), MEP-108A, PRECISE CLASS, 50 HERTZ (6115-00-935-8729) {LO 07536A-12} 020614 LO 5-6115-465-12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MOUNTED, 30 3 PHASE, 4 WIRE, 120/206 AND 240/416 V (DOD MODEL MEP-055A), UT CLASS, 50/60 HZ (NSN 6115-00-118-1240); (MODEL MEP 104A), PRECI CLASS, 50/60 HZ (6115-00-118-1247) AND (MODEL 114A) PRECISE CLA 400 HZ (6115-00-118-1248) 025150 TM 5-6115-271-14 12 GENERATOR SET, GASOLINE ENGINE DRIVEN, S MTD, TUBULAR FRAME, 3 KW, 3 PHASE, AC, 120/208 AND 120/240 V, 2 DC (LESS ENGINE) DOD MODEL MEP-016A, 60 HZ (NSN 6115-00-017-823 MODEL MEP-016C 60 HZ (6115-00-143-3311) MODEL MEP-021A 400 HZ (6115-00-017-8238) MODEL MEP-021C 400 HZ (6115-01-175-7321) MODEL MEP-026A DC HZ (6115-00-017-8239) MODEL MEP-026C 28 V DC (6115-01-175-7320) {TO 35C2-3-386-1; TM 05926A-14; NAVFAC P-8-6 025151 TM 5-6115-271-24P 3 GENERATOR SET, GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULA FRAME, 3 KW, 3 PHASE, AC; 120/208 AND 120/240 VOLTS, 28 VDC (LE ENGINE) (DOD MODEL MEP-016A) 60 HERTZ (NSN 6115-00-017-8237) (MEP-021A) 400 HERTZ (6115-00-017-8238) (MEP-026A) 28 VDC HERTZ (6115-00-017-8239) (MEP-016C) 60 HERTZ (6115-01-143-3311) (MEP- 400 HERTZ (6115-01-175-7321) (MEP-026C) 28 VDC HERTZ (6115-01-175-7320) {TO 35C2-3-386-4; SL-4-05926A} 032507 TM 5-6115-275-14 10 GENERATOR SET, GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULAR FRAME, 10 KW, AC, 120/208V PHASE, AND 120/240V, SINGLE PHASE, LESS ENGINE: DOD MODELS MEP- HZ, (NSN 6115-00-889-1447) AND MEP-023A, 400 HZ (6115-00-926-08 {NAVFAC P-8-615-14; TO 35C2-3-452-1} (THIS ITEM IS INCLUDED ON EM 0086, EM 0088 & EM 0127) 032508 TM 5-6115-275-24P 5 GENERATOR, GASOLINE ENGINE DRIVEN, SKID MOUNTED, TUBULAR FRAME, 10 KW, AC, 120/208 V, 3 PHASE AND 120/240 V, SINGLE PHASE (LESS ENGINE); D MEP-018A, UTILITY CLASS, 60 HZ (NSN 6115-00-889-1447) AND MEP-0 PRECISE CLASS, 400 HZ (6115-00-926-0843) {NAVFAC P8-615-24P; TO 35C2-3-452-4} (THIS ITEM IS INCLUDED ON EM 0086, EM 0088 & EM 0127) 032551 TM 5-6115-584-12 11 GENERATOR SET,

DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 5 KW, 1 PHASE, 2 WIRE; 1 PHASE, 3 WIRE; 3 PHASE, 4 WIRE, 120, 120/240 AND 120/208 V (DOD MODEL MEP-002A) UTILITY CLASS, 60 HZ (NSN 6115-00-465-1044) {NAVFAC P-8-622-12; TO 35C2-3-456-1; TM 05682C-12} 032640 TM 5-6115-585-12 12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 10 KW, 1 PHASE, 2 WIRE 1 PHASE, 3 WIRE AND 3 PHASE, 4 WIRE; 120, 120/240 AND 120/208 V (DOD MODEL MEP-003A) UTILITY CLASS, 60 HZ (NSN 6115-00-465-1030 AND (MODEL MEP-112A), UTILITY CLASS, 400 HZ (6115-00-465-1027) {NAVFAC P-8-623-12; TO 35C2-3-455-1; TM-05684C/05685B-12} 032781 TM 5-6115-584-34 8 GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MOUNTED, 5 KW, 1 PHASE, 2 WIRE, 1 PHASE, 3 WIRE, 3 PHASE, 120, 120/240 AND 120/208 V (DOD MODEL MEP-002A), UTILITY CLASS, (NSN 6115-00-465-1044) {NAVFAC P-8-622-34; TO 35C2-3-456-2; TM 0568C-34} 032936 TM 5-6115-329-14 4 GENERATOR SET GASOLINE ENGINE DRIVEN, 0.5 KW (LESS ENGINE) (DOD MODEL MEP-014 UTILITY CLASS, 60 HZ) (NSN 6115-00-923-4469), (DOD MODEL MEP-01 UTILITY CLASS, 400 HZ (6115-00-940-7862) AND (DOD MODEL MEP-024 UTILITY CLASS, 28 VDC (6115-00-940-7867) {TO 35C2-3-440-1} 033374 TM 5-6115-332-14 10 GENERATOR SET, TAC GASOLINE ENGINE: AIR COOLED, 5 KW, AC, 120/240 V, SINGLE PHASE, V, 3 PHASE, SKID MOUNTED, TUBULAR FRAME (LESS ENGINE) (MILITARY DOD MODEL MEP-017A), UTILITY, 60 HZ (NSN 6115-00-017-8240) AND MODEL MEP-022A), UTILITY, 400 HZ (6115-00-017-8241) {NAVFAC P-8-614-14; TO 35C2-3-424-1} 033750 TM 5-6115-585-34 9 GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MOUNTED, 10 KW, 1 PHASE, 2 WIRE, 1 PHASE, 3 WIRE, 3 PHASE, 4 WIRE, 120, 120/240 AND 120/208 VOLTS (DOD MODEL MEP-003A), UT CLASS, 60 HZ (NSN 6115-00-465-1030) {NAVFAC P-8-623-12; TO 35C2-3-455-2; TM-05684C/05685B-34} 034072 TM 5-6115-585-24P 5 GENERATOR SET, DIESEL ENGINE DRIVEN, TA SKID MTD, 10 KW, 1 PHASE, 2 WIRE; 1 PHASE, 3 WIRE; 3 PHASE, 4 W 120, 120/240 AND 120/208 V (DOD MODELS 003A), UTILITY CLASS, 60 (NSN 6115-00-465-1030) AND (MODEL MEP-112A), UTILITY CLASS, 400 (6115-00-465-1027) {NAVFAC P-8-623-24P; TO 35C2-3-455-4; SL-4-05684C/06585B} 040180 TM 5-6115-584-12-HR HAND RECEIPT MANUAL COVERING END ITEM/COMPONENTS OF END ITEM (C BASIC ISSUE ITEMS (BII), AND ADDITIONAL AUTHORIZATION LIST (AAL GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 5 KW, 1 WIRE; 1 PH, 3 WIRE; 3 PH, 4 WIRE, 120, 120/240 AND 120/208 V (DOD MODEL MEP-002A) UTILITY CLASS, 60 HZ (NSN 6115-00-465-1044) 040833 TM 5-6115-458-12-HR HAND RECEIPT MANUAL COVERING THE END ITEM/COMPONENTS OF END ITE BASIC ISSUE ITEMS (BII), AND ADDITIONAL AUTHORIZATION LIST (AA GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MOUNTED, 20 3 PHASE, 4 WIRE, 120/208 AND 240/416 V (DOD MODEL MEP-009A), UT CLASS, 50/60 HZ (NSN 6115-00-133-9104) AND (DOD MODEL MEP-108A) PRECISE CLASS, 50/60 HZ (6115-00-935-8729) 040843 TM 5-6115-593-34 GENERATOR SET, DIESEL ENGINE DRIVEN, TAC SKID MTD, 500 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS DOD MODEL, MEP-029A, CLASS UTILITY, 50/60 HZ, (NSN 6115-01-030- DOD MODEL, MEP-029B, CLASS UTILITY, 50/60 HZ, (6115-01-318-6302 INCLUDING OPTIONAL KITS DOD MODEL, MEP-029AHK, HOUSING KIT, (6115-01-070-7550), DOD MODEL, MEP-029ACM, AUTOMATIC CONTROL MO (6115-01-275-7912) DOD MODEL, MEP-029ARC, REMOTE CONTROL MODULE (6110-01-070-7553) DOD MODEL, MEP-029ACC, REMOTE CONTROL CABLE, (6110-01-087-4127) {NAVFAC P-8 041070 TM 5-6115-593-12 GENERATOR SET, ENGINE DRIVEN, TACTICAL SKID MTD, 500 KW, 3 PHASE, 4 WIRE; 120/ 240/416 VOLTS DOD MODEL MEP-029A; CLASS UTILITY, HERTZ 50/60; (NSN 6115-01-030-6085); MEP-029B; UTILITY; 50/60; (6115-01-318- INCLUDING OPTIONAL KTS DOD MODELS MEP-029AHK; NOMENCLATURE HOUS (6115-01-070-7550) MEP-029ACM; AUTOMATIC CONTROL MODULE; (6115-01-275-7912); MEP-029ARC, REMOTE CONTROL MODULE, (6110-01-070-7553); MEP-029ACC, REMOTE CONTROL CABLE (6110-01-087-4127) {TO 35C2-3-463-1} 041338 LO 55-1730-229-12 POWER UNIT, AVIATION, MULTI-OUTPUT GTED ELECTRICAL, HYDRAULIC, PNEUMATIC (AGPU), WHEEL MOUNTED, SELF-PROPELLED, TOWABLE DOD MODEL-MEP-360A, CLASS-PRECISE, HERTZ-400, (NSN 1730-01-144-1897 042791 TM 5-6115-457-12-HR HAND RECEIPT MANUAL COVERING THE

BASIC ISSUE ITEMS (BII) FOR GE SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MTD; 100 KW, 3 PHASE, 120/208 AND 240/416 V (DOD MODELS MEP007A), UTILITY CLASS, 50/6 (NSN 6115-00-133-9101), (MODEL MEP-106A), PRECISE CLASS, 50/60 (6115-00-133-9102) AND (MODEL MEP116A) PRECISE CLASS, 400 HZ (6115-00-133-9103) 043437 TM 5-6115-593-24P 1 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MOUNTED, 500 KW, 3 PHA 4 WIRE; 120/208 AND 240/416 VOLTS DOD MODEL MEP-029A UTILITY CL 50/60 HZ (NSN 6115-01-030-6085) MEP-029B UTILITY CLASS, 50/60 (6115-01-318-6302) INCLUDING OPTIONAL KITS DOD MODEL MEP-029AHK HOUSING KIT (6115-01-070-7550) MEP-029ACM AUTOMATIC CONTROL MOD (6115-01-275-7912) MEP-029ARC REMOTE CONTROL MODULE (6110-01-070-7553) MEP-029ACC REMOTE CONTROL CABLE (6110-01-087 {NAVFAC P-8-631-24P; TO 35C2-3-463-4} 044703 TM 5-6115-545-12-HR HAND RECEIPT MANUAL COVERING COMPONENTS OF END ITEM (COEI), BAS ITEMS (BII), AND ADDITIONAL AUTHORIZATION LIST (AAL) FOR GENERA DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 60 KW, 3 PHASE, 4 WIRE 120/208 AND 240/416 V (DOD MODELS MEP-006A) UTILITY CLASS, 50/6 (NSN 6115-00-118-1243), (MODEL MEP-105A) PRECISE CLASS, 50/60 H (6115-00-118-1252) AND (MODEL MEP-115A) PRECISE CLASS, 400 HZ (6115-00-118-1253) 050998 TM 5-6115-600-12 8 GENERATOR DIESEL ENGINE DRIVEN, TACTICAL SKID MTD, 100 KW, 3 PHASE, 4 WIR 120/208 AND 240/416 V (DOD MODEL MEP-007B) CLASS UTILITY, 50/60 (NSN 6115-01-036-6374) INCLUDING OPTIONAL KITS, DOD MODEL MEP00 WINTERIZATION KIT, FUEL BURNING AND MEP007BWE WINTERIZATION KIT ELECTRIC 051007 TM 5-6115-600-24P 4 GENERATOR SET, DIESEL ENGINE DRIVEN, 100 KW, 3 PHASE, 4 WIRE, 120/208 AND VOLTS (DOD MODEL MEP-007B), UTILITY CLASS, 50/60 HZ (NSN 6115-01-036-6374) INCLUDING OPTIONAL KITS, DOD MODEL MEP007BWF, WINTERIZATION KIT, FUEL BURNING AND MEP007BWE WINTERIZATION KIT, ELECTRIC {TO 35C2-3-442-14; NAVFAC P-8-628-24P; SL-4-07464B} 057268 LO 5-6115-600-12 GENERATOR SET, DIESEL ENGINE DRIVEN; TACTICAL, SKID MTD, 100 KW PHASE, 4 WIRE; 120/208 AND 240/416 V (DOD MODEL MEP007B), CLASS UTILITY, 50/60 HZ (NSN 6115-01-036-6374) 057513 LO 5-6115-604-12 GENERATOR SET, DIESEL ENGINE DRIVEN, AIR TRANSPORTABLE; SKID MT 750 KW, 3 PHASE, 4 WIRE; 2400/4160 AND 2200/3800 VOLTS (DOD MOD MEP208A) CLASS PRIME UTILITY, HZ 50/60 (NSN 6115-00-450-5881) {LI 6115-12/9} 060183 TM 5-6115-612-24P 6 GENERATOR SET, AVIATION, GAS TURBINE ENGINE DRIVEN, INTEGRA TRAILER MOUNTED, 10KW, 28 VOLTS MODEL MEP-362A, PRECISE, DC (NSN 6115-01-161-3992) {TM 6115-24P/1; AG-320B0-IPE-000; TO 35C2-3-471-4} 060188 TM 5-6115-612-34 4 GENERATOR SET, AVIATION, GAS TURBINE ENG DRIVEN, INTEGRAL TRAILER MOUNTED 10KW 28 VOLTS DOD MODEL MEP 36 PRECISE, DC, (NSN 6115-01-161-3992) {AG-320BO-MME-000; TM 6115- TO 35C2-3-471-2} 060645 LO 5-6115-612-12 AVIATION GENERATOR SET, GAS TURBINE, ENGINE DRIVEN, INTEGRAL TR MOUNTED, 10KW, 28 VOLTS DC DOD MODEL MEP 362A CLASS PRECISE (NSN 6115-01-161-3992) 060921 TM 55-1730-229-34 5 POWER UNIT, AVIATION, MULTI-OUTPUT GTED, ELECTRICAL, HYDRAULIC, PNEUMATIC (AGPU) WHEEL MOUNTED, SELF-PROPELLED, TOWA AC 400HZ, 3PH, 0.8 PF, 115/200V, 30 KW, DC 28VDC 700 AMPS, PNEUMATIC, 60 LBS/MIN. AT 40 PSIG, HYDRAULIC, 15 GPM AT 3300 PS DOD MODEL MEP-360A, CLASS PRECISE, 400 HERTZ, (NSN 1730-01-144- {AG 320A0-MME-000; TO 35C2-3-473-2; TM 1730-34/1} 060922 TM 55-1730-229-12 8 POWER UNIT, AVIATION, MULTI-OUTPUT GTED ELECTRICAL, HYDRAULIC, PNEUMATIC (AGPU) WHEEL MOUNTED, SELF-PROPELLED, TOWABLE, AC 400HZ, 3PH, 0.8 PF, 115/200V, 30 KW, DC 28 VDC 700 AMPS, PNEUMATIC 60 LBS/M AT 40 PSIG, HYDRAULIC 15 GPM AT 3300 PSIG, DOD MODEL MEP-360A, CLASS PRECISE, HERTZ 400, (NSN 1730-01-144-1897) {AG 320A0-OMM-000; TO 35C2-3-473-1; TM 1730-12/1} 061758 LO 5-6115-614-12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD. 200 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS MODEL MEP009B, UTILI 50/60 HERTZ, (NSN 6115-01-021-4096) 061772 LO 5-6115-622-12 GENERATOR SET, DIESEL ENGINE-DRIVEN, WHEEL MOUNTED 750-KW, 3-PH 4-WIRE, 2200/3800 AND 2400/4160 VOLTS CUMMINS ENGINE COMPANY IN MODEL KTA-2300G-2 DOD MODEL MEP-012A; CLASS UTILITY; HERTZ 062762 LO 5-6115-615-12

GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MOUNTED, 3 K MODEL 016B;
 CLASS UTILITY MODE 50/60 HZ (NSN 6115-01-150-4140); DOD MODEL MEP-021B; CLASS
 UTILITY; MODE 400 HZ (6115-01-151-812 DOD MODEL MEP-026B; CLASS UTILITY; MODE 28
 VDC (6115-01-150-036 {LI 05926B/06509B-12/5; P-8-646-LO} 064310 TM 5-6115-626-14&P 2
 POWER UNIT PU-406B/M (NSN 6115-00-394-9576) MEP-005A 30 KW 60 HZ GENERATOR SET
 M200A1 2-WHEEL4-TIRE, MODIFIED TRAILER 064390 TM 5-6115-632-14&P 5 POWER UNIT
 PU-753/M (NSN 6115-00-033-1 MEP-003A 10 KW 60 HZ GENERATOR SET M116A2 2-WHEEL,
 2-TIRE, MODI TRAILER 064392 TM 5-6115-629-14&P 3 POWER PLANT AN/AMJQ-12A (NSN
 6115-00-257-1602) (2) MEP-006A 60HZ, GENERATOR SETS (2) M200A1 2-WHEEL, 4-TIRE,
 MODIFIED TRAIL 064443 TM 5-6115-625-14&P 2 POWER UNIT PU-405A/M (NSN
 6115-00-394-9577) MEP-004A 15 KW 60 HZ GENERATOR SET M200A1 2-WHEEL, 4-TIRE,
 MODIFIED TRAILER (THIS ITEM IS INCLUDED ON EM 0086 & EM 0087) 064445 TM
 5-6115-633-14&P 4 POWER PLANT AN/MJQ-18 (NSN 6115-00-033-1398) (2) MEP-003A 1 60 HZ
 GENERATOR SETS M103A3 2-WHEEL 1 1/2 TON MODIFIED TRAILER 064446 TM
 5-6115-628-14&P 4 POWER PLANT AN/MJQ-15 (NSN 6115-00-400-7591) (2) MEP-113A 1 400 HZ
 GENERATOR SETS, (2) M200A1 2-WHEEL, 4-TIRE, MODIFIED TRA (THIS ITEM IS INCLUDED ON
 EM 0086) 064542 TM 5-6115-631-14&P 4 POWER PLANT AN/MJQ-16 (NSN 61 15-00-033-1395) (2)
 MEP-002A 5 KW 60 HZ GENERATOR SETS M103A3 2-WHEEL, 2-TIRE, MODIFIED TRAI 065071 TM
 55-1730-229-24P 6 POWER AVIATION, MULTI-OUTPUT GTED ELECTRICAL, HYDAULIC,
 PNEUMATIC (AG WHEEL MOUNTED, SELF-PROPELLED, TOWABLE AC 400 HZ, 3 PH, 0.8 PF,
 115/200V, 30 KW DC 28 VDC 700 AMPS PNEUMATIC 60 LBS/MIN. AT 40 HYDRAULIC 15 GPM AT
 3300 PSIG DOD MODEL MEP-360A, CLASS PRECISE 400 HERTZ (NSN 1730-01-144-1897) {TO
 35C2-3-473-4; TM 1730-24P/ AG 320A0-IPB-000} 065603 TB 5-6115-593-24 WARRANTY PROGRAM
 FOR GENERATOR SET DOD MODEL MEP-029A HOUSING K DOD MODEL MEP-029AHK 066727
 TM 5-6115-640-14&P 2 POWER AN/MJQ-32 (NSN 6115-01-280-2300) AN/MJQ-33
 (6115-01-280-2301) (MEP-701A 3KW 60 HZ ACOUSTIC SUPPRESSION KIT GENERATOR SETS
 M116 2-WHEEL, 2-TIRE, 3/4-TON MODIFIED TRAILERS 066808 TM 5-6115-627-14&P 2 POWER
 PLANT AN/MJQ-10A (NSN 6115-00-394-9582); (2) MEP-005A 30 KW 60 HZ GEN SETS; (2) M200A1
 2-WHEEL, 4 TIRE MODIFIED TRAILERS 066809 TM 5-6115-630-14&P 4 POWER UNIT, PU-751/M
 (NSN 6115-00-033-1373) MEP-002A, 5 KW, 60 HZ GENERATOR SET M116A1 2-WHEEL, 2-TIRE,
 MODIFIED TRAILER 066824 TM 5-6115-465-10-HR 1 HAND RECEIPT MANUAL COVERING END
 ITEM/COMPONENTS OF END ITEM (C BASIC ISSUE ITEMS, (BII) AND ADDITIONAL
 AUTHORIZATION LIST (AAL GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID
 MOUNTED, 30K 4 WIRE, 120/208 AND 240/416 VOLTS - MEP-005A, UTILITY, 50/60 HE (NSN
 6115-00-118-1240); MEP-104A, PRECISE, 50/60 HERTZ, (6115-00-118-1247): MEP-114A, PRECISE,
 400 HERTZ, (6115-00-118- INCLUDING AUXILIARY EQUIPMENT MEP-005AWF WINTERIZATION
 KIT, FUE BURNING (6115-00-463-9083); MEP-005AWE, WINTERIZATION KIT, ELEC (6115-00
 067310 TM 9-6115-650-14&P 1 POWER PLAN AN/MJQ-25 (NSN 6115-01-153-7742) (2) MEP-112A
 10 KW 400 HZ GENE SETS M103A3 2-WHEEL, 2-TIRE, MODIFIED TRAILER 067311 TM
 9-6115-653-14&P 2 POWER UNIT PU-732/M (NSN 6115-00-260-3082) MEP-113A 15 KW 400 HZ
 GENERATOR SET M200 2-WHEEL, 4-TIRE, MODIFIED TRAILER 067544 TM 9-6115-652-14&P 1
 POWER UNIT PU-760/M (NSN 6115-00-394-9581) MEP-114A 30 KW 400 HZ GENERATOR M200A1
 2-WHEEL, 4-TIRE, MODIFIED TRAILER 067632 TM 9-6115-648-14&P POWER UNIT PU-650B/G
 (NSN 6115-00-258-1622) MEP-006A 60 KW 60 HZ GENERATOR M200A1 2-WHEEL, 4-TIRE,
 MODIFIED TRAILER 067744 TM 9-6115-646-14&P 1 POWER UNIT PU-495A/G, (NSN
 6115-00-394-9575) AND PU-495B/G, (6115-01-134-0 MEP-007A 100 KW, 60 HZ OR MEP-007B, 100
 KW, 60 HZ GENERATOR SET M353-2-WHEEL, 2-TIRE MODIFIED TRAILER 067746 TM
 9-6115-651-14&P POWER UNIT 707A/M (NSN 6115-00-394-9573) MEP-115A, 60 KW, 400 HZ
 GENERATOR M200A1, 2-WHEEL, 4-TIRE, MODIFIED TRAILER 067879 TM 9-6115-647-14&P 1
 POWER UNIT PU-789/M (NSN 6115-01-208-9827) MEP-114A, 30 KW 400 HZ GENERATOR SET
 M353 2-WHEEL, 2-TIRE, MODIFIED TRAILER 069601 TM 9-6115-464-10-HR HAND RECEIPT

MANUAL COVERING THE END ITEMS/COMPONENTS OF END IT (COEI), BASIC ISSUE ITEMS (BII), AND ADDITIONAL AUTHORIZATION L (AAL) FOR GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MO 15 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS DOD MODEL MEP UTILITY CLASS, 50/60 HERTZ (NSN 6115-00-118-1241) DOD MODEL MEP PRECISE CLASS, 50/60 HERTZ (6115-00-118-1245) DOD MODEL MEP-113 PRECISE CLASS, 400 HERTZ (6115-00-118-1244) 069602 LO 9-6115-464-12 GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL, SKID MTD, 15KW, 4 WIRE, 120/208 AND 240/416 VOLTS (DOD MODEL MEP 004A) (NSN 6115-00-118-1241); (DOD MODEL MEP 104A) (6115-00-118-1245) (DOD MODEL MEP-113A) (6115-00-118-1244) 069954 TM 9-6115-465-24P 2 GENERATOR SET, DIESEL ENGINE DRIVE TACTICAL SKID MTD. 30KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 V MODELS; MEP-005A, UTILITY, 50/60 HZ, (NSN 6115-00-118-1240), MEP-104A PRECISE, 50/60 HZ, (6115-00-118-1247), MEP-114A, PRECISE, 400 H (6115-00-118-1248), INCLUDING OPTIONAL KITS, DOD MODELS; MEP-00 WINTERIZATION KIT, FUEL BURNING, (6115-00-463-9083), MEP-005-AW WINTERIZATION KIT, ELECTRIC, (6115-00-463-9085), MEP-002-ALM, L BANK KIT, (6115-00-463-9088), MEP-005-AWM, WHEEL MOUNTING KIT, (6115-00-463-9094) {TO-35C2-3-070096 TM 9-6115-464-24P 1 GENERATOR S DIESEL ENGINE DRIVEN, TACTICAL SKID MTD., 15KW, 3 PHASE, 4 WIRE 120/208 AND 240/416 VOLTS (DOD MODEL MEP-004A) UTILITY CLASS 50/60 HERTZ (NSN 6115-00-118-1241) (DOD MODEL MEP-103A) PRECISE CLASS 50/60 HERTZ (6115-00-118-1245) (DOD MODEL MEP-113A) PRECI CLASS 400 HERTZ (6115-00-118-1244) INCLUDING OPTIONAL KITS (DOD MODEL MEP-005-AWF) WINTERIZATION KIT, FUEL BURNING (6115-00-463 (DOD MODEL MEP-005-AWE) WINTERIZATION KIT, ELECTRIC (6615-00-46 (DOD MODEL MEP-004-ALM) LOAD BANK KIT (6115-00-191-9201 071025 TM 9-6115-641-10 2 GENERATOR SET SKID MOUNTED, TACTICAL QUIET 5 KW, 60 AND 400 HZ MEP-802A (60 HZ) (NSN 6115-01-274-7387) MEP-812A (400 HZ) (6115-01-274-7391) {TO 35C2-3-456-11} 071026 TM 9-6115-642-10 2 GENERATOR SET SKID MOUNTED, TACTICAL QUIE 10 KW, 60 AND 400 HZ MEP-803A (60 HZ) (NSN 6115-01-275-5061) MEP-813A (400 HZ) (6115-01-274-7392) {TO 35C2-3-455-11; TM 09247A/09248A-10/1} 071028 TM 9-6115-643-10 3 GENERATOR SET, SKID MOUNTED, TACTICAL QUI 15 KW, 50/60 AND 400 HZ MEP-804A (50/60 HZ) (NSN 6115-01-274-73 MEP-814A (400 HZ) (6115-01-274-7393) {TO 35C2-3-445-21} 071029 TM 9-6115-644-10 2 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ MEP-805A (50/60 HZ), (NSN 6115-01-274-7389) MEP-815A (400 HZ), (6115-01-274-7394) {TO 35C2-3-446-11; TM 09249A/09246A-10/1} 071030 TM 9-6115-645-10 2 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 60 KW, 50/60 AND 400 HZ MEP-806A (50/60 HZ), (NSN 6115-01-274-7390) MEP-816A (400 HZ), (6115-01-274-7395) {TO 35C2-3-444-11; TM 09244A/09245A-10/1} 071031 LO 9-6115-641-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 5 KW, 60 AND 400 HZ MEP-802A TACTICAL QUIET 60 HZ (NSN 6115-01-274-7387) MEP-812A TACTICAL QUIET 400 HZ (6115-01-274-7391) 071032 LO 9-6115-642-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 10 KW, 60 AND 400 H MEP-803A TACTICAL QUIET 60 HZ (NSN 6115-01-275-5061) MEP-813A TACTICAL QUIET 400 HZ (6115-01-274-7392) 071033 LO 9-6115-643-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 15 KW, 50/60/400 HZ MEP-804A TACTICAL QUIET 50/60 HZ (NSN 6115-01-274-7388) MEP-814 TACTICAL QUIET 400 HZ (6115-01-274-7393) 071034 LO 9-6115-644-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 40 MEP-805A TACTICAL QUIET 50/60 HZ (NSN 6115-01-274-7389) MEP-815 TACTICAL QUIET 400 HZ (6115-01-274-7394) {LI 09249A/09246A-12} 071035 LO 9-6115-645-12 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 60 KW, 50/60 AND 40 MEP-806A TACTICAL QUIET 50/60 HZ (NSN 6115-01-274-7390) MEP-816 TACTICAL QUIET 400 HZ (6115-01-274-7395) {LI 09244A/09245A-12} 071036 TB 9-6115-641-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 5 KW, 60 AND 400 HZ MEP-802A AND MEP-812A 071037 TB 9-6115-642-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 10 KW, 60 AND 400 HZ MEP-803A AND MEP-813A {SI 09247A/09248A-24} 071038 TB 9-6115-643-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 15 KW, 50/60 AND 400 HZ MEP-804A AND MEP-814A 071039 TB 9-6115-644-24

WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ
MEP-805A AND MEP-815A {SI 09249A/09246A-24} 071040 TB 9-6115-645-24 WARRANTY
PROGRAM FOR GENERATOR SET, TACTICAL QUIET 60 KW, 50/60 AND 400 HZ MEP-806A AND
MEP-816A {SI 09244A/09245A-24} 071541 TM 9-6115-464-12 2 GENERATOR SET, DIESEL
ENGINE DRIVEN, TACTICAL SKID MTD, 15 KW, 3 PHASE, 4 WIRE, 120/2 AND 240/416 VOLTS
DOD MODEL MED-004A UTILITY CLASS 50/60 HERTZ (NSN 6115-00-118-1241) DOD MODEL
MEP-103A PRECISE CLASS 50/60 HERTZ (6115-00-118-1245) DOD MODEL MEP-113A PRECISE
CLASS 400 HERTZ (6115-00-118-1244) INCLUDING OPTIONAL KITS DOD MODEL MEP-005-AWF
WINTERIZATION KIT, FUEL BURNING (6115-00-463-9083) DOD MODEL MEP-005-AWE
WINTERIZATION KIT, ELECTRIC (6115-00-463-9085) DOD MODEL MEP-004-ALM LOAD BANK KIT
(6115-00-291 071604 TM 9-6115-645-24P GENERATOR SET, TACTICAL QUIET 60KW, 50/60/400
HZ (NSN 6115-01-274-7390) (MEP-806A) (6115-01-274-7395) (MEP-816A) {TO 35C2-3-444-14; TM
09244A/09245A-24P/3} 071605 TM 9-6115-642-24P GENERATOR SET, TACTICAL QUIET 10 KW,
60/400 HZ (NSN 6115-01-275-5061) (MEP-803A) (6115-01-274-7392) (MEP-813A) {TO
35C2-3-455-14; TM 09247A/09248A-24P/3} 071610 TM 9-6115-643-24P GENERATOR SET,
TACTICAL QUIET 15KW, 50/60 - 400 HZ (NSN 6115-01-274-7388) (MEP-804A) (6115-01-274-7393)
(MEP-814A) {TO 35C2-3-445-24} 071611 TM 9-6115-644-24P GENERATOR SET, TACTICAL QUIET
30KW, 50/60-400 HZ (NSN 6115-01-274-7389) (MEP-805A) (6115-01-274-7394) (MEP-815A) {TO
35C2-3-446-14; TM 09249A/09246A-24P/3} 071613 TM 9-6115-641-24P GENERATOR SET,
TACTICAL QUIET 5 KW, 60/400 HZ (NSN 6115-01-274-7387) (MEP-802A) (6115-01-274-7391)
(MEP-812A) {TO 35C2-3-456-14} 071713 TM 9-6115-645-24 4 GENERATOR SET, SKID MOUNTED,
TACTICAL QUIET 60KW, 50/60 AND 400 HZ MEP-806A (50/60 HZ) (NSN 6115-01-274-7390)
MEP-816A (400 HZ) (6115-01-274-7395) {TO 35C2-3-444-12; TM 09244A/09245A-24/2} 071748 TM
9-6115-644-24 1 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ
MEP-805A (50/60 HZ) (NSN 6115-01-274-7389) MEP-815A (400 HZ) (6115-01-274-7394) {TO
35C2-3-446-12; TM 09249A/09246A-24/2} 071749 TM 9-6115-643-24 4 GENERATOR SET, SKID
MOUNTED, TACTICAL QUIET 15 KW, 50/60 AND 400 HZ MEP-804A (50/60 HZ) (NSN
6115-01-274-7388) MEP-814A (400 HZ) (6115-01-274-7393) {TO 35C2-3-445-22} 071750 TM
9-6115-642-24 4 GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 10 KW, 60 AND 400 HZ
MEP-803A (60 HZ) (NSN 6115-01-275-5061) MEP-813A (400 HZ) (6115-01-274-7392) {TO
35C2-3-455-12; TM 09247A/09248A-24/2} 071751 TM 9-6115-641-24 3 GENERATOR SET, SKID
MOUNTED, TACTICAL QUIET 5 KW, 60 AND 400 HZ MEP-802A (60 HZ) (NSN 6115-01-274-7387)
MEP-812A (400 HZ) (6115-01-274-7391) {TO 35C2-3-456-12} 072239 TM 9-6115-464-34 1
GENERATOR SET, DIESEL ENGINE DRIVEN, TACTICAL SKID MTD., 15 KW, 3 PHASE, 4 WIRE
120/208 AND 240/416 VOLTS DOD MODEL MEP-004A UTILITY CLASS 50/60 HERTZ (NSN
6115-00-118-1241) DOD MODEL MEP 103A PRECISE CLASS 50/60 HERTZ (6115-00-118-1245)
DOD MODEL MEP-113A PRECISE CLASS 400 HERTZ (6115-00-118-1244) INCLUDING OPTIONAL
KITS DOD MODEL MEP-005AWF WINTERIZATION KIT, FUEL BURNING (6115-00-463-9083) DOD
MODEL MEP-005AWE WINTERIZAT KIT, ELECTRIC (6115-00-463-9085) DOD MODEL
MEP-004ALM LOAD BANK KIT (6115-00-291-920 073744 TM 9-6115-604-24P 1 GENERATOR SET,
DIESEL ENGINE DRIVEN, AIR TRANSPORTABLE SKID MOUNTED, 750KW, 3 PHASE, 4 WIRE,
2400/4160, AND 2200/3800 VOLTS DOD MODEL MEP208A PRIME UTILITY CLASS 50/60 HERTS
(NSN 6115-00-450-5881) DOD MODEL 80-1466 REMOTE CONTROL MODULE CLASS
(6115-01-150-5284 DOD MODEL 80-7320 SITE REQUIREMENTS MODULE CLASS (6115-01-150-5
{NAVFAC P-8-633-24P} 074040 TM 9-6115-545-24P GENERATOR SET, DIESEL ENGINE DRIVEN,
TAC SKID MTD., 60 KW, 3 PHASE, 4 WIRE, 120/208 AND 240/416 VOLTS, D MODELS MEP-006A,
UTILITY CLASS, 50/60 H/Z, (NSN 6115-00-118-124 MEP-105A, PRECISE CLASS, 50/60 H/Z,
(6115-00-118-1252), MEP-115 PRECISE CLASS, 400 H/Z (6115-00-118-1253); INCLUDING
OPTIONAL K DOD MODELS MEP-006AWF, WINTERIZATION FUEL BURNING, (6115-00-407
MEP-006AWE, WINTERIZATION KIT, ELECTRIC, (6115-00-455-7693), ME LOAD BANK KIT,
(6115-00-407-8322), AND MEP-006AWM, WHEEL MOUNTI (6115-00-463-9092) {TO 074212 TM

9-6115-604-12 GENERATOR SET, DIESEL DRIVEN, AIR TRANSPORTABLE SKID MTD., 750 KW, 3 PHASE, 4 WIRE, 24 AND 2200/3800 V (DOD MODEL MEP 208A) CLASS PRIME UTILITY, HZ 50 (NSN 6115-00-450-5881) {NAVFAC P-8-633-12} 074896 TM 9-6115-604-34 GENERATOR SET, DIESEL ENGINE DRIVEN, AIR TRANSPORTABLE SKID MTD., 750 KW, 3 PHASE, 4 WIRE, 2400/4160 AND 2200/3800 VOLTS DOD MODEL MEP 208A PRIME UTILITY CLASS 50/60 HERTZ (NSN 6115-00-450-5881) {NAVFAC P-8-633-34} 075027 TM 9-6115-584-24P 1 GENERATOR SET, DIESEL E DRIVEN, TACTICAL SKID MTD 5 KW, 1 PHASE -2 WIRE, 1 PHASE -3 WIR 3 PHASE -4 WIRE, 120, 120/240 AND 120/208 VOLTS (DOD MODEL MEP- UTILITY CLASS, 60 HZ (NSN 6115-00-465-1044) {NAVFAC P-8-622-24P TO 35C2-3-456-4} 077581 TM 9-6115-673-13&P 2KW MILITARY TACTICAL GENERATOR SET 120 VAC, 60 HZ (NSN 6115-01-435-1565) (MEP-531A) (EIC: LKA) (NSN 6115-21-912-0393) (MECHRON) 28 VDC (NSN 6115-01-435-1567) (MEP-501A) (EIC: LKD) (NSN 6115-21-912-0392) (MECHRON) 078167 TM 9-6115-672-14 GENERATOR SET SKID MOUNTED TACTICAL QUIET 60KW, 50/60 AND 400 HZ, MEP-806B (50/60 HZ) (NSN 6115-01-462-0291) EIC: GGW, MEP-816B (400 HZ) (NSN 6115-01-462-0292) EIC: GGX 078443 TM 9-6115-639-13 1 3KW TACTICAL QUIET GENERATOR SET MEP 831A (60 HZ) (NSN 6115-01-285-3012) (EIC: VG6) MEP 832A (400 HZ) (NSN 6115-01-287-2431) (EIC: VN7) 078490 TM 9-6115-671-14 OPERATOR, UNIT, GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ, MEP-805B (50/60 HZ) (NSN 6115-01-461-9335) (EIC: GGU) MEP-815B (400 HZ) (6115-01-462-0290) (EIC: GGV) 078503 TM 9-6115-671-24P GENERATOR SET SKID MOUNTED, TACTICAL QUIET 30 KW, 50/60 AND 400 HZ MEP-805B (50/60 HZ) (NSN 6115-01-461-9335) (EIC: GGU) MEP-815B (400 HZ) (NSN 6115-01-462-0290) (EIC: GGV) 078504 TM 9-6115-672-24P GENERATOR SET, SKID MOUNTED, TACTICAL QUIET 60 KW, 50/60 AND 400 HZ MEP-806B (50/60 HZ) (NSN 6115-01-462-0291) (EIC: GGW) MEP-816B (400 HZ) (NSN 6115-01-462-0292) (EIC: GGX) 078505 TB 9-6115-671-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 30KW, 50/60 AND 400 HZ MEP-805B AND MEP-815B PROCURED UNDER CONTRACT DAAK01-96-D-00620WITH MCII INC 078506 TB 9-6115-672-24 WARRANTY PROGRAM FOR GENERATOR SET, TACTICAL QUIET 30KW, 50/60 AND 400 HZ MEP-806B AND MEP-816B PROCURED UNDER CONTRACT DAAK01-96-D-00620WITH MCII INC 078523 TM 9-6115-664-13&P 5KW, 28VDC, AUXILIARY POWER UNIT (APU) MEP 952B NSN 6115-01-452-6513 (EIC: N/A) 078878 TM 9-6115-639-23P 3KW TACTICAL QUIET GENERATOR SET MEP 831A (60 HZ) (NSN 6115-01-285-3012) (EIC: VG6) MEP 832A (400 HZ) (NSN 6115-01-287-2431) (EIC: VN7) 079379 TB 9-6115-641-13 WINTERIZATION KIT (NSN 6115-01-476-8973) INSTALLED ON GENERATOR SET, SKID MOUNTED, TACTICAL QUIET, 5KW, 60 AND 400 HZ MEP-802A (600HZ) (6115-01-274-7387) MEP-812A (400HZ) (6115-01-274-7391) 079460 TB 9-6115-642-13 WINTERIZATION KIT (NSN 6115-01-477-0564) (EIC: N/A) INSTALLED ON GENERATOR KIT, SKID MOUNTED, TACTICAL QUIET, 10KW, 60 AND 400 HZ MEP-803A (60HZ) (6115-01-275-0561) MEP-813A (400HZ) (6115-01-274-7392) 079461 TB 9-6115-643-13 WINTERIZATION KIT (NSN 6115-477-0566) INSTALLED ON GENERATOR SET, SKID MOUNTED, TACTICAL QUIET, 15KW, 50/60 AND 400 HZ, MEP-804A (50/60HZ) (6115-01-274-7388) MEP-814A (400HZ) (6115-01-274-7393) 079462 TB 9-6115-644-13 WINTERIZATION KIT (NSN 6115-01-474-8354) (EIC:N/A) INSTALLED ON GENERATOR SET, SKID MOUNTED, 30KW, 50/60 AND 400 HZ MEP-805A (50/60HZ) (NSN 6115-01-274-7389) MEP-815A (400HZ) (NSN 611501-274-7394) 079463 TB 9-6115-645-13 WINTERIZATION KIT (NSN 6115-01-474-8344) (EIC: N/A) INSTALLED ON GENERATOR SET, SKID MOUNTED, TACTICAL QUIET, 60KW, 50/60 AND 400 HZ, MEP-806A (50/60HZ) (6115-01-274-7390) MEP-816A (400HZ) (6115-01-274-7395) 080214 TM 9-6115-670-14&P AUXILIARY POWER UNIT, 20KW, 120/240 VAC, 60 HZ, MODEL NO. MEP-903A(SICPS) NSN 6115-01-431-3062 MODEL NUMBER MEP-903B (JTACS) NSN 6115-01-431-3063 MODEL NO MEP-903C9WIN-T) NSN 6115-01-458-5329 (EIC: N/A)

wiring diagram head unit: Drawings for the Pickwick Landing Project Tennessee Valley Authority. Engineering and Construction Departments, 1948

wiring diagram head unit: Drawings for the Watauga and Wilbur Projects Tennessee

Valley Authority. Divisions of Engineering and Construction, 1955 This report is an index of engineering drawings for the Watauga and Wilbur Dam projects.

wiring diagram head unit: Bibliography of Scientific and Industrial Reports , 1946

wiring diagram head unit: Chilton's Power Accessories and Wiring Diagrams Manual

Chilton Book Company. Automotive Editorial Department, 1973

wiring diagram head unit: Technical Manual United States Department of the Army, 1961

wiring diagram head unit: 1973-74 ASTM Manual for Rating Motor, Diesel and Aviation Fuels American Society for Testing and Materials, 1973

wiring diagram head unit: United States Army X-ray Manual United States. Surgeon General's Office. Division of Roentgenology, 1920

Related to wiring diagram head unit

All About Electrical Wiring Types, Sizes & Installation Learn the basics of electrical wiring for the home, including wire and cable types, wire color codes and labeling, and essential wiring techniques

Electrical Wiring Types, Sizes and Installation - Family Handyman Conquer your fear of working with electrical wiring BY understanding the basics of electrical work and installing 3-switch wiring. Play it smart and stay safe when attempting DIY electrical

Home Wiring 101 - Basic Electrical Wiring for Homeowners It is helpful for every DIY-minded homeowner to have at least a basic understanding of electrical work. This article will attempt to reveal some of the mystery surrounding the maze

From the Ground Up: Electrical Wiring - This Old House Our guide will walk you through the essentials of home electrical wiring, from planning and installation to safety considerations and future-proofing your system

Electrical wiring - Wikipedia Electrical wiring is an electrical installation of cabling and associated devices such as switches, distribution boards, sockets, and light fittings in a structure. Wiring is subject to safety

The Ultimate Guide to Wiring: A Step-by-Step Tutorial for Beginners Get the ultimate guide to wiring with step-by-step instructions, diagrams, and tips. Learn everything from basic electrical concepts to advanced techniques for residential and

Electrical Wiring: Components, Types & Safety Basics Electrical wiring refers to the installation of cabling and associated devices such as switches, distribution panels, outlets, and light fittings within a structure. It is essential to every

7 Common Electrical Wiring Types: The Good, Bad, & Power In this article, we will explore seven common types of electrical wiring, each with its own set of advantages and drawbacks. Whether you're a homeowner, a DIY enthusiast, or a professional

Wiring - Fine Homebuilding With advice from the master electricians who have contributed to this comprehensive guide, you'll be able to approach any wiring project with confidence, whether it's as straightforward as

The Ultimate Guide to Electrical Wiring Installation: Step-by-Step Learn how to install electrical wiring with this comprehensive guide. Get step-by-step instructions and safety tips on proper installation techniques

All About Electrical Wiring Types, Sizes & Installation Learn the basics of electrical wiring for the home, including wire and cable types, wire color codes and labeling, and essential wiring techniques

Electrical Wiring Types, Sizes and Installation - Family Handyman Conquer your fear of working with electrical wiring BY understanding the basics of electrical work and installing 3-switch wiring. Play it smart and stay safe when attempting DIY electrical

Home Wiring 101 - Basic Electrical Wiring for Homeowners It is helpful for every DIY-minded homeowner to have at least a basic understanding of electrical work. This article will attempt to

reveal some of the mystery surrounding the maze

From the Ground Up: Electrical Wiring - This Old House Our guide will walk you through the essentials of home electrical wiring, from planning and installation to safety considerations and future-proofing your system

Electrical wiring - Wikipedia Electrical wiring is an electrical installation of cabling and associated devices such as switches, distribution boards, sockets, and light fittings in a structure. Wiring is subject to safety

The Ultimate Guide to Wiring: A Step-by-Step Tutorial for Beginners Get the ultimate guide to wiring with step-by-step instructions, diagrams, and tips. Learn everything from basic electrical concepts to advanced techniques for residential and

Electrical Wiring: Components, Types & Safety Basics Electrical wiring refers to the installation of cabling and associated devices such as switches, distribution panels, outlets, and light fittings within a structure. It is essential to every

7 Common Electrical Wiring Types: The Good, Bad, & Power In this article, we will explore seven common types of electrical wiring, each with its own set of advantages and drawbacks. Whether you're a homeowner, a DIY enthusiast, or a professional

Wiring - Fine Homebuilding With advice from the master electricians who have contributed to this comprehensive guide, you'll be able to approach any wiring project with confidence, whether it's as straightforward as

The Ultimate Guide to Electrical Wiring Installation: Step-by-Step Learn how to install electrical wiring with this comprehensive guide. Get step-by-step instructions and safety tips on proper installation techniques

Related to wiring diagram head unit

aftermarket head unit + wiring harness = um, should I have extra wires? (Ars Technica22y)
Probably a dumb question, but I'd really like to know I'm not doing anything wrong before ripping my dashboard apart.

Dramatis personae:

- Jensen MP3-510 CD/mp3 player.
"The

aftermarket head unit + wiring harness = um, should I have extra wires? (Ars Technica22y)
Probably a dumb question, but I'd really like to know I'm not doing anything wrong before ripping my dashboard apart.

Dramatis personae:

- Jensen MP3-510 CD/mp3 player.
"The

Back to Home: <http://www.devensbusiness.com>